


## CX5 Liftgate System Layout



### ① Electronic Locking Mechanism



### ② Outside Latch Button




### ③ Back Button

NOTE: Use included drill bit to mount button



### Component Locator



### Height Adjustment

Manually adjust liftgate to preferred height. Press FRONT BUTTON until system beeps 2 times, then release. Cycle system to verify height adjustment.

### Speed Adjustment

Hold TAILGATE BUTTON until system beeps 5 times, then release

10 Quick Beeps = Fast  
1 Long Beep = Slow (Default)

