



Call Voxx Support for technical assistance:
1-800-645-4994
 9 AM – 6 PM (EST - Eastern) Monday – Friday

① Electronic Locking Mechanism

② Reverse Light


③ Outside Latch Button





Control Box Mounting Location

NOTE: Under the Wiper Motor



Height Adjustment

Manually adjust liftgate to preferred height. Press FRONT BUTTON until system beeps 2 times, then release. Cycle system to verify height adjustment.

Speed Adjustment

Hold TAILGATE BUTTON until system beeps 5 times, then release

10 Quick Beeps = Fast
1 Long Beep = Slow (Default)

Component Locator

